


ozone

DSP27^{PRO}

27" LED GAMING MONITOR



USER MANUAL




#WithinTheGame

INPUT VOLTAGE

AC 100-240V - 50/60Hz
DC12V  4A

KEY FUNCTION (JOYSTICK)



- LEFT** - Move to left to select among four crosshair options.
- UP** - Contrast menu direct access.
- DOWN** - Direct access to HDR option (ON/OFF).
- RIGHT** - Input source; Brightness / Contrast; Color adjustment; Image quality adjustment; Screen setting; Sound setting; OSD menu; Others

- Press button to turns the monitor ON/OFF.
- Navigate into menú with joystick movements (up, down, left and right).

TECHNICAL SPECS

Resolution	2560 x 1440 px
Dimensions	610 x 410-540 x 130 mm
Without stand	610 x 360 x 8 mm
Net weight	6.5 Kg
Gross weight	7.8 Kg
Included cables	1x 12V Adapter; 1x HDMI; 1x Display Port

CONNECTIVITY





STATEMENT OF COMPLIANCE WITH EUROPEAN UNION DIRECTIVES

Ozone declares that this product is in compliance with the essential requirements and other relevant provisions from the following Directive: 2014/30/EU, as applicable. The technical documentation required by the Conformity Evaluation process is in Ozone's possession and can be requested through info@ozonegaming.com



DISPOSAL OF BATTERIES AND ELECTRICAL OR ELECTRONIC EQUIPMENT WASTE

The existence of this symbol on the product, batteries or respective packaging, signifies that this product and the contained batteries can not be disposed as domestic waste.

It is the user's responsibility to deliver this product at a batteries, electrical or electronic recycling pick-up point.

The pick-up and separate recycling contributes for the preservation of natural resources and suppresses potential negative consequences for the human health and the environment resultant of inadequate disposal of dangerous substances contained in batteries and electrical or electronic equipment.

For additional informations regarding batteries, electrical or electronic recycling pick-up points, please contact your local municipal services.

WARRANTY

Who does the warranty protect:

This warranty is valid for the original purchaser only.

What does the warranty protect:

For warranty claims, please contact Ozone's overseas distribution partners in your country. Find the distribution partner list at www.ozonegaming.com
Warranty: 2 years from the purchasing date. (Depending on the laws of each country)

URL: www.ozonegaming.com

E-mail: support@ozonegaming.com

Ozone reserves the right for any modifications in text and/or images.

What does not the warranty cover:

1. Any product, on which the serial number has been defaced, modified or removed.

2. Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
3. Repair or attempted repair by anyone not authorized by Ozone Gaming.
4. Damage to or loss of any programs, data or removable storage media.
5. Software or data loss occurring during repair or replacement.
6. Any damage of the product due to shipment.
7. Removal or installation of the product.
8. External causes, such as electric power fluctuations or failure.
9. Use of supplies or parts not meeting Ozone Gaming's specifications.
10. Normal wear and tear.
11. Any other cause which does not relate to a product defect.

If you have any questions regarding technical problems, please contact us via our website: www.ozonegaming.com

Ozone reserves the right for any modifications in text and/or images.

LCD MONITOR PIXEL POLICY

Panel manufacturers set limits as to how many defective dots (or sub-pixels) are deemed to be acceptable on any LCD panel.

Ozone's manufacturer warranty covers any defects that exceed the defect specifications described in this document.

LCD displays are made of pixels. Each pixel is made up of a red, green and blue sub-pixel, each sub pixel are driven by an individual transistor. If a transistor becomes defective, the corresponding dot may be permanently light (bright) or may not light (dark). Independently of the brand and the manufacturer, it is common for one or more sub-pixels to become fixed in an unchanging state. The defective pixel/sub-pixel phenomenon is as follows:

- (1) Color white - a bright sub-pixel (always ON)
- (2) Color black - a dark sub-pixel (always OFF)
- (3) Color red, green or blue - a stuck sub-pixel (always ON or always OFF)

The specifications for the number of defects that are deemed to be acceptable for the specified size of LCD panel is:

Panel Type	Native resolution	Bright Sub-pixel	Dark Sub-pixel	Total allowable Sub-pixel
Quad HD (QHD)	2560x1440 px	3	3	5

NOTE: Specification is subject to change without notice and may vary from different regions.

WARNING



WARNING/CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN



TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that the interference will not occur in a particular installation.

IMPORTANT SAFETY INSTRUCTIONS

11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the unit. When a cart is used, use caution when moving the cart/monitor combination to avoid injury from tip-over.



13. Unplug this product during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Do not expose this product to dripping or splashing and ensure that no objects fill with liquids, such as vases, are placed on the unit.



#WithinTheGame

www.ozonegaming.com